

How to Use a Dell Docking Station

To use monitors with your laptop, start by connecting laptop using the black Docking Station cable:

Note: While there are two ways to connect, the first method is preferred. Only use the second method if you do not have any USB-C ports on your computer. Newer docking stations do not include the adapter.

Picture1.png or type unknown OR Picture2a.png or type unknown

To set up and change how the monitors mirror or extend your laptop screen, right-click on the desktop and select "Display Settings"

mseclip0.png or type unknown

The computer labels each monitor including the laptop screen with a number. Click "Identify" to see which monitor is which number, then you can move them into the formation you wish and press apply.

Picture3.jpg or type unknown

In this example, the laptop (#1) and monitor #2 are mirroring, while monitor #3 is placed to the right and is extending. If you want to extend all monitors, select the 1/2 Box as shown, then scroll down and change "Duplicate these displays" to "Extend these displays."

Troubleshooting

If you are having issues with your Dell Dock including:

- Keyboard/Mouse not responding
- *Screens not displaying (additional solution below)
- Unreliable internet connection through the dock

Running the program "Dell Command | Update" will usually resolve most of these issues. Check the start menu for the program as it should already be installed.

mseclip0.png or type unknown

If it doesn't show on your start menu, you will need to go to

<https://www.dell.com/support/home/Drivers/DriversDetails?driverId=DDVDP> to download and install it.

1. When you open Dell Command | Update, if you get the popup for setup, choose the first option and click OK

Image not found in type: unknown
HOW10760_en_US_9dcw8

2. Click the "Check" button

Image not found in type: unknown
HOW10760_en_US_10DCUPicture4

3. Once the check completes, if updates have been identified, you can then click the "Install" button

Image not found in type: unknown
HOW10760_en_US_11DCUPicture3

4. Wait for the updates to complete (some functions may temporarily reset such as the screens flickering during this process). Then you can close the program

Image not found in type: unknown
HOW10760_en_US_13DCU-five-of-five

5. Often you will need to restart the computer to finalize the updates.

*Sometimes these updates do not install the needed drivers for the monitors. For this, [click here](#) and install the displaylink driver file.

If you are still experiencing issues, try the following process after completing the updates:

1. Remove the Docking Station cable from the computer.
2. Unplug AC power from the Docking Station (usually has a blue light).
3. Drain any remaining power to the Docking Station by holding the power button for 30 seconds (if you have a power button on your model).
4. Plug AC power back into the Docking Station.
5. Plug the Docking Station cable back into the computer.

Revision #1

Created 30 April 2024 16:04:52 by Matthew Witt

Updated 2 May 2024 17:42:16 by Matthew Witt